



universität  
wien




CHRISTIAN DOPPLER LABORATORY FOR  
MID-IR SPECTROSCOPY &  
SEMICONDUCTOR OPTICS

# High Finesse Mirror Design, Fabrication and Characterization

Oliver Heckl



# Mirror and Optical Coating Technical Overview




Two main classes of thin-film reflective optical coatings:


simple metallic mirrors	single or protected Ag, Al, or Au layer	broadband, but high losses
interference coatings	alternating transparent dielectric films	very versatile, low losses

## Reflectivity for prevalent metal mirrors


Comparison of Aluminum Coatings  
(Unpolarized, 45° AOI)



Comparison of Silver Coatings  
(Unpolarized, 45° AOI)




Comparison of Gold Coatings  
(Unpolarized, 45° AOI)




- Very broadband reflection for ranging from VUV/VIS to mid-IR wavelengths
- Percent-level losses at best  $\rightarrow$  bad candidates for high-Finesse mirrors

## How to do better – optical interference coatings



- Alternating layers of high / low index (quarter-wave thickness) thin films
  - at Bragg wavelength internal reflections add in phase, max. reflectivity

## Reflection and Refraction



**Figure 6.2-1** Reflection and refraction at the boundary between two dielectric media.

## Fresnel Equations


$$r_x = \frac{n_1 \cos \theta_1 - n_2 \cos \theta_2}{n_1 \cos \theta_1 + n_2 \cos \theta_2}, \quad t_x = 1 + r_x,$$
$$r_y = \frac{n_1 \sec \theta_1 - n_2 \sec \theta_2}{n_1 \sec \theta_1 + n_2 \sec \theta_2}, \quad t_y = (1 + r_y) \frac{\cos \theta_1}{\cos \theta_2}.$$

(6.2-8)  
TE Polarization


(6.2-9)  
TM Polarization  
Fresnel Equations

With Snell's law:  $\cos \theta_2 = \sqrt{1 - \sin^2 \theta_2} = \sqrt{1 - (n_1/n_2)^2 \sin^2 \theta_1}$

## TE Polarization / s-Polarization: External Reflection; $n_1 < n_2$




**Figure 6.2-2** Magnitude and phase of the reflection coefficient as a function of the angle of incidence for *external reflection* of the *TE-polarized wave* ( $n_2/n_1 = 1.5$ ).




Note: reflection on optically denser medium introduces a  $\pi$  phase shift

## TE Polarization / s-Polarization: Internal Reflection; $n_1 > n_2$




**Figure 6.2-3** Magnitude and phase of the reflection coefficient as a function of the angle of incidence for *internal reflection* of the *TE-polarized* wave ( $n_1/n_2 = 1.5$ ).




Note: reflection on optically less dense medium introduces no phase shift up to the critical angle



## TM Polarization / p-Polarization: External Reflection; $n_1 < n_2$




**Figure 6.2-4** Magnitude and phase of the reflection coefficient as a function of the angle of incidence for *external reflection* of the *TM-polarized wave* ( $n_2/n_1 = 1.5$ ).




Note: reflection on optically denser medium introduces a  $\pi$  phase shift

## TM Polarization / p-Polarization: Internal Reflection; $n_1 > n_2$





**Figure 6.2-5** Magnitude and phase of the reflection coefficient as a function of the angle of incidence for *internal reflection* of the *TM-polarized wave* ( $n_1/n_2 = 1.5$ ).



Note: reflection on optically less dense medium introduces no phase shift up to Brewster-angle


## Basic idea of a distributed bragg reflector (DBR)




$n_i$ : incident  
 $n_H$ : high  
 $n_L$ : low  
 $n_s$ : substrate  
 $T$ : transmission (intensity)  
 $R$ : reflectivity (intensity)  
 $\lambda_B$ : Bragg wavelength

- Individual reflections from each material boundary are added in phase  
Remember: reflection on optically denser medium introduces a  $\pi$  phase shift
- $\lambda_B$ : twice the optical thickness of a layer pair

## Calculation of DBR-stacks



# Calculation of DBR-stacks



$r_{l,l+t}$ : reflectivity (field) at interface  $l,l+1$

$t_{l,l+1}$ : transmissoin (field) at interface  $l,l+1$

$\delta_l$ : accumulated phase by passing layer  $l$

## Transmission from layer $l$ to $l+1$

$$v_{l+1} = e^{i\delta_l} t_{l,l+1} v_l + r_{l,l+1} w_{l+1}$$


$$w_l = e^{2i\delta_l} r_{l,l+1} v_l + e^{i\delta_l} t_{l,l+1} w_{l+1}$$

## Clever matrix formulation

$$\begin{pmatrix} v_l \\ w_l \end{pmatrix} = \frac{1}{t_{l,l+1}} \begin{pmatrix} e^{-i\delta_l} & 0 \\ 0 & e^{i\delta_l} \end{pmatrix} \begin{pmatrix} 1 & r_{l,l+1} \\ r_{l,l+1} & 1 \end{pmatrix} \begin{pmatrix} v_{l+1} \\ w_{l+1} \end{pmatrix} = M_l \begin{pmatrix} v_{l+1} \\ w_{l+1} \end{pmatrix}$$

$$\tilde{M} = \prod_{i=0}^{2N} M_l$$

# Calculation of DBR-stacks



$r_{l,l+t}$ : reflectivity (field) at interface  $l,l+1$

$t_{l,l+1}$ : transmissoin (field) at interface  $l,l+1$

$\delta_l$ : accumulated phase by passing layer  $l$

## Transmission from layer $l$ to $l+1$

$$v_{l+1} = e^{i\delta_l} t_{l,l+1} v_l + r_{l,l+1} w_{l+1}$$

$$w_l = e^{2i\delta_l} r_{l,l+1} v_l + e^{i\delta_l} t_{l,l+1} w_{l+1}$$

## Clever matrix formulation

$$\begin{pmatrix} v_l \\ w_l \end{pmatrix} = \frac{1}{t_{l,l+1}} \begin{pmatrix} e^{-i\delta_l} & 0 \\ 0 & e^{i\delta_l} \end{pmatrix} \begin{pmatrix} 1 & r_{l,l+1} \\ r_{l,l+1} & 1 \end{pmatrix} \begin{pmatrix} v_{l+1} \\ w_{l+1} \end{pmatrix} = M_l \begin{pmatrix} v_{l+1} \\ w_{l+1} \end{pmatrix}$$

$$\tilde{M} = \prod_{i=0}^{2N} M_i \quad \begin{pmatrix} 1 \\ r \end{pmatrix} = \tilde{M} \begin{pmatrix} t \\ 0 \end{pmatrix}$$



Incident light on DBR

Reflected light from DBR

Transmitted light through DBR

Incident light on exit-facet of the DBR

# Basic idea of a distributed bragg reflector (DBR)



Matrix formulation:

$$\begin{pmatrix} 1 \\ r \end{pmatrix} = \tilde{M} \begin{pmatrix} t \\ 0 \end{pmatrix} = \begin{pmatrix} \tilde{M}_{0,0} & \tilde{M}_{0,1} \\ \tilde{M}_{1,0} & \tilde{M}_{1,1} \end{pmatrix} \begin{pmatrix} t \\ 0 \end{pmatrix}$$




Transmission and reflection coefficients

$$r = r(\lambda, \theta) = \frac{\tilde{M}_{0,1}}{\tilde{M}_{0,0}}; \quad R = r^2 t$$


$$t = t(\lambda, \theta) = \frac{1}{\tilde{M}_{0,0}}; \quad T = \frac{n_2 \cos \theta_2}{n_1 \cos \theta_1} t^2$$

TMM-Fast Python package

## Buildup of mirror and stopband: substrate only




substrate









# Buildup of mirror and stopband: $N = 0$





substrate





# Buildup of mirror and stopband: $N = 1$





## Buildup of mirror and stopband: $N = 2$





# Buildup of mirror and stopband: $N = 3$





# Buildup of mirror and stopband: $N = 4$





# Buildup of mirror and stopband: $N = 5$



## Buildup of mirror and stopband: $N = 6$





# Buildup of mirror and stopband: $N = 8$








# Buildup of mirror and stopband: $N = 10$




# Buildup of mirror and stopband: $N = 15$





## Buildup of mirror and stopband: $N = 20$





Very decent mirror  
with ppm-level  
transmission, further  
layers will not  
increase reflectivity



# Buildup of mirror and stopband: $N = 25$



# Buildup of mirror and stopband: $N = 30$



# Analytical insights: width of stopband and angle-tuning

Fresnes reflection (0° AOI):

$$r = \frac{n_H - n_L}{n_H + n_L}$$


Relative width of stopband:

$$\frac{\Delta\omega}{\Delta\omega_B} = \frac{4}{\pi} \sin^{-1} r$$


Technology	$n_H$	$n_L$	Relative width
Epitaxially grown semiconductors	~3.6	~3.0	~10%
Amorphous coatings (IBS)	2.1 (Ta <sub>2</sub> O <sub>5</sub> ) 2.35 (TiO <sub>2</sub> )	1.37 (MgF <sub>2</sub> ) 1.45 (SiO <sub>2</sub> )	~30%

**Higher contrast (large  $\Delta n$ ) allows for wider stopband and fewer layers for a given reflectivity**



Change in reflectance with varying AOI



Change in reflectance with varying AOI



## Excursion: chirped DBRs and dispersion measurements



### Chirped Distributed Bragg reflectors

- Spectrally dependent phase shifts due to different penetration depths
- GDD optimized designs possible

Group delay dispersion can be measured in an FTS if the sample is placed in one arm and not before the spectrometer



universität  
wien



CHRISTIAN DOPPLER LABORATORY FOR  
MID-IR SPECTROSCOPY &  
SEMICONDUCTOR OPTICS



# High Finesse Mirror Design, Fabrication and Characterization






# Optical Coating Technologies

Physical Vapor Deposition (PVD) of current amorphous coatings



- 1857 Arc Evaporation
- 1907 E-beam Evaporation
- 1939 Magnetron Sputtering
- 1979 Ion-beam Sputtering


Substrate-Transferred crystalline semiconductor supermirrors



2012 Crystalline Coatings

**New state-of-the-art low-loss mirrors:**  
 State-of-the-art multilayer mirrors:  
 GaAs/AlGaAs deposited via ion-beam sputtered Ta<sub>2</sub>O<sub>5</sub>/SiO<sub>2</sub> molecular beam epitaxy

## E-beam evaporation



- Rotating substrates to ensure coating homogeneity
- Substrate temperature between 150 and 400°C

Evaporation sources heated by e-beam or resistive heating

### Challenges:

- Low packing density allows atmospheric water to enter coating → absorption and shift of stopband
- Formation of micro crystallites leading to high scattering losses (up to percent level)

### Advantages

- High laser damage thresholds and low absorption
- Often used for laser mirrors
- Best technology for UV-mirrors


# Sputtering

Extraction of ionized particles by ion bombardment  
→ acceleration with electric fields and deposition on substrate



## Magnetron Sputtering

- Gas discharge in front of target
- Potentially combined with reactive gas to create compounds



## Ion Beam Sputtering (IBS)

- Separate ion source generates target ions and reactive gas (oxygen)




## Advantages

- **Gold standard** for mirror production from VIS-NIR
- High laser damage thresholds and low absorption
- Fully amorphous microstructure (no micro crystallites)
- High package density (no water-vapor issues)
- High mechanical stability

## Challenges:



- Mid-IR wavelength coverage (relatively high absorption)
- Amorphous structure leads to scattering losses

## Molecular Beam Epitaxy (MBE)



- Molecular beam epitaxy is employed to grow single-crystal GaAs/AlGaAs heterostructures
- The single-crystalline multilayer is removed and directly bonded to a super-polished (curved) substrate
- Alternating layers GaAs/ $\text{Al}_{0.92}\text{Ga}_{0.08}\text{As}$  form distributed Bragg reflector

## Molecular Beam Epitaxy (MBE) – Crystalline Mirrors



### Challenges:

- Involved (and expensive) production process
- Low  $\Delta n \rightarrow$  reduced relative stopband compared to near-IR mirror technology ( $\sim 10\%$ )

### Advantages

- High thermal conductivity
- Minimal absorption in mid-IR spectral range (sensitive mid-IR spectroscopy, high cavity transmission)
- Negligible scatter due to crystalline surface quality
- Excellent Brownian noise performance (reference cavities, gravitational wave detection, ring-laser gyroscopes, ...)
- Potential for **ppm-level optical losses** in the mid-IR



universität  
wien





CHRISTIAN DOPPLER LABORATORY FOR  
MID-IR SPECTROSCOPY &  
SEMICONDUCTOR OPTICS

# High Finesse Mirror Design, Fabrication and Characterization




## Low Loss Crystalline Coatings

28.5 period  
GaAs/AlGaAs  
crystalline coating






single-crystal Si (SCS) substrate




- Monocrystalline mirror discs transferred to curved substrates
- Alternating layers GaAs/Al<sub>0.92</sub>Ga<sub>0.08</sub>As form distributed Bragg reflector
- Potential for **ppm-level optical losses** in the mid-IR

# Crystalline Coatings






## Predicting Transmission via a Model Based on FTIR and SEM Data



	Loss (ppm)	$\lambda_{min}$ (nm)
<b>T (design)</b>	142	4500

# Fourier-Transform Spectroscopy



Resolution:  $\Delta\nu = \frac{1}{2L} > f_{\text{rep}}$


Typical value:  $\approx 6 \text{ GHz} - 1.8 \text{ MHz}$

Comb:  
 $\Delta\nu \approx 10 \text{ kHz}; L = 1 \text{ m}$

See summer school lecture of Lucile Rutkowski on  
“Cavity-enhanced optical frequency comb spectroscopy”

Corresponds to  $L = 15 \text{ km} !!!$

# Fourier-Transformation Spectroscopy




Resolution:  $\Delta\nu = \frac{1}{2L} > f_{\text{rep}}$

Typical value:  $\approx 6 \text{ GHz} - 1.8 \text{ MHz}$

Comb:

$\Delta\nu \approx 10 \text{ kHz}; L = 1 \text{ m}$

Corresponds to  $L = 15 \text{ km} !!!$





Poster: L. Perner, *et al.*

“High-Accuracy Measurement of Mid-IR Refractive Indices of GaAs/AlGaAs in Thin-Film Multilayers”

L. Perner, M. Prinz, O. H. Heckl, Mid-infrared refractive index of crystalline thin-film GaAs/AlGaAs multilayers, writeup in progress

# Predicting Transmission via a Model Based on FTIR and SEM Data



	Loss (ppm)	$\lambda_{min}$ (nm)
T (design)	142	4500
T (FTIR corr.)	144 ± 2	4538 ± 1

- FTIR can be used to determine growth (thickness) errors and thus the center wavelength
- **However**, this system cannot independently resolve the minimum transmission value

# Loss Components in Optical Interference Coatings

$$T + A + S = 1 - R$$

$l$  ... Excess loss  
 $L$  ... Total loss

**Precise measurements at ppm level challenging, most often not provided by manufacturers.**  
**→ A major inhibition for progress in the field!**

Transmission ( $T$ )

Absorption ( $A$ )

Scatter ( $S$ )

Reflectance ( $R$ )

Design parameter, controlled by # of mirror periods and index contrast

Determined by free-carrier absorption

Measure of surface and bond quality

Final reflectivity defined by total losses


**Excess losses:**  
 Scatter and absorption reduce cavity transmission

$$\frac{P_{\text{trans}}}{P_{\text{in}}} \propto \frac{T^2}{L^2}$$

- typical micro-roughness of  $< 0.2$  nm leads to  $S < 5$  ppm in NIR


**Assumption:**  
 $< 1$  ppm in mid-IR

- aim is to achieve  $I < T$
- determines cavity enhancement and linewidth (finesse)



# Excess Loss Measurements


## Transmission (T)



### Direct transmission

Simple, but high-precision direct transmission measurement


## Absorption (A)



### Photothermal common-path interferometry (PCI)

Allows for direct absorption measurements < 10 ppm (<1 ppm with W-level pump)

## Reflectance (R)




### Cavity ring-down (CRD)

Broadband (~200 nm) QCL @ 4.55 μm with passive feedback

# Excess Loss Measurements


## Transmission (T)



### Direct transmission

Simple, but high-precision direct transmission measurement


## Absorption (A)



### Photothermal common-path interferometry (PCI)

Allows for direct absorption measurements < 10 ppm (<1 ppm with W-level pump)


## Reflectance (R)



### Cavity ring-down (CRD)

Broadband (~200 nm) QCL @ 4.55 μm with passive feedback


## Direct Transmission Measurement (DIRT)



- Differential measurement
  - To deal with QCL probe power fluctuation
- Lock-in detection
  - enhances detector sensitivity given the low power per wavelength
  - increase of detector dynamic range (allowing measurement of  $P_{in}$  and  $P_{trans}$  with same detector)
- Blocking of stray light is crucial for a trustworthy measurement



## DIRT Measurement Results




	Loss (ppm)	$\lambda_{min}$ (nm)
<b>T (design)</b>	142	4500
<b>T (FTIR corr.)</b>	144 ± 2	4538 ± 1
<b>T (measured)</b>	143 ± 3	4536 ± 5

- We observe excellent agreement between direct measurements and FTIR-corrected transmission values – accurate dispersion curves.

# Excess Loss Measurements


## Transmission (T)



### Direct transmission

Simple, but high-precision direct transmission measurement


## Absorption (A)



### Photothermal common-path interferometry (PCI)

Allows for direct absorption measurements < 10 ppm (<1 ppm with W-level pump)


## Reflectance (R)



### Cavity ring-down (CRD)

Broadband (~200 nm) QCL @ 4.55 μm with passive feedback


# Measuring Optical Absorption via Photothermal Commonpath Interferometry (PCI)



Sensitivity limit below 10 ppm with  
our current 4.5  $\mu\text{m}$  QCL pump laser


Alexandrovski, Photothermal common-path interferometry:  
new developments. SPIE 7193 (2009)

# Absorption Measurements via Photothermal Common Path Interferometry (PCI)




$$\frac{AC}{DC \cdot P} = R \cdot \alpha$$

- $\alpha$  ... Absorption
- $R$  ... Responsivity
- $AC$  ... Amplitude of probe signal modulation at pump chopping frequency
- $DC$  ... Average probe signal
- $P$  ... Average pump power at pump/probe crossing



## PCI setup



$$\frac{AC}{DC \cdot P} = R \cdot \alpha$$

$\alpha$	... Absorption
$R$	... Responsivity
$AC$	... Amplitude of probe signal modulation at pump chopping frequency
$DC$	... Average probe signal
$P$	... Average pump power at pump/probe crossing


### Calibration

- Sample on same substrate with ~40% absorption

### Measurement

- Relative comparison of signals allows measurement of <40 ppm absorption

# PCI setup



$$\frac{AC}{DC \cdot P} = R \cdot \alpha$$

- $\alpha$  ... Absorption
- $R$  ... Responsivity
- $AC$  ... Amplitude of probe signal modulation at pump chopping frequency
- $DC$  ... Average probe signal
- $P$  ... Average pump power at pump/probe crossing

## Calibration

- Sample on same substrate with ~40% absorption

## Measurement

- Relative comparison of signals allows measurement of <40 ppm absorption


# PCI calibration

$$\frac{AC}{DC \cdot P} = R \cdot \alpha$$

## Standard calibration (using calibration piece)


- $$P_{\text{absorbed}} = P_{\text{in}} - P_{\text{refl}} - P_{\text{trans}}$$

$$\alpha_{\text{calib}} = \frac{P_{\text{absorbed}}}{P_{\text{in}}}$$




- $$\alpha_{\text{calib}} \rightarrow R$$

↑  
(%-level)



- $$R \rightarrow \alpha_{\text{sample}}$$

↑  
(ppm-level)




## In-Situ calibration (using „proxy pump“)

- Check equal spotsize for both pumps (e.g. via equal R)


- $$\alpha_{\text{proxy}} = \frac{P_{\text{absorbed}}}{P_{\text{in}}}$$

- $$\alpha_{\text{proxy}} \rightarrow R$$

- $$R \rightarrow \alpha_{\text{sample}}$$



# PCI setup



- Challenges of extension to Mid-IR:
- Low-power pump
  - Substrate response / absorption
  - Thermal lens contribution by thicker coatings
  - Probe-induced absorption
  - Atmospheric effects
  - Polarization-dependence

$$\frac{AC}{DC \cdot P} = R \cdot \alpha$$

- $\alpha$  ... Absorption
- $R$  ... Responsivity
- $AC$  ... Amplitude of probe signal modulation at pump chopping frequency
- $DC$  ... Average probe signal
- $P$  ... Average pump power at pump/probe crossing

## Calibration


- Sample on same substrate with ~40% absorption

## Measurement

- Relative comparison of signals allows measurement of <40 ppm absorption





# PCI Measurement Results



	Loss (ppm)	$\lambda_{min}$ (nm)
<b>T (measured)</b>	$143 \pm 3$	$4536 \pm 5$
<b>A (measured)</b>	$< 20$	4550-4700

- PCI reveals an upper limit of for optical absorption (4.55-4.70  $\mu\text{m}$ )
- The broad spectral range of the QCL pump overstates absorption losses in the stopband center.


# Polarization-dependent Absorption



- First-time observation of this effect – allowed to optimize mirror orientation in cavity for lowest losses.
- Data in agreement with density functional theory model of uniaxially strained GaAs.

# Excess Loss Measurements


## Transmission (T)



### Direct transmission

Simple, but high-precision direct transmission measurement


## Absorption (A)



### Photothermal common-path interferometry (PCI)

Allows for direct absorption measurements < 10 ppm (<1 ppm with W-level pump)

## Reflectance (R)



### Cavity ring-down (CRD)


Broadband (~200 nm) QCL @ 4.55 μm with passive feedback

# Measuring Total Loss $L = (1-R)$ via Cavity Ringdown (CRD)

$$R + T + A + S = 1$$


$$\underbrace{\hspace{10em}}_L$$

$$\tau = \frac{d}{cL}$$




$$\tau = \frac{d}{cL}$$

Independent of laser intensity fluctuations!



## CRD with Broadband Excitation



$$R + T + A + S = 1$$

$$\tau = \frac{d}{cL}$$

Finesse

$$\mathcal{F} := \frac{f_{FSR}}{\delta f} = \frac{\pi c}{d} \tau$$


- Tuneable source (e.g. DFB QCL)
  - Narrow tuning range
  - Expensive
- Broadband source (e.g. FP QCL)
  - High coupling loss (incoupled power ratio given by Finesse)
  - Feedback

QCL ... Quantum cascade laser

DFB ... direct feedback


FP ... Fabry Perot

# Characterization of Total Loss via Cavity Ringdown



- 4.55  $\mu\text{m}$  Fabry-Perot QCL without isolation and no servo system
- Delay stage to match external cavity and enhance feedback
- Monochromator for wavelength resolved measurements

# Ultralow-Loss 4.5 μm Optical Interference Coatings



	Loss (ppm)	$\lambda_{min}$ (nm)
<b>T (measured)</b>	$143 \pm 3$	$4536 \pm 5$
<b>T+A+S (CDL)</b>	$153 \pm 1$	$4534 \pm 1$
<b>T+A+S (NIST)</b>	$149 \pm 6$	$4533 \pm 1$

- Independent measurements at the CDL and NIST (team around A. Fleisher) show excellent results
  - excess optical losses (absorption + scatter) below 10 ppm!
- Potential for enhancement cavities with a finesse  $>100,000$  @ 4.5 μm

G. Winkler, L. W. Perner, et al., "Mid-infrared interference coatings with excess optical loss below 10 ppm," *Optica* **8**, 686-696 (2021)  
<https://doi.org/10.1364/OPTICA.405938>

# Summary

## Distributed Bragg Reflectors

- Principle
- Calculation of stop-bands

## Production techniques and wavelength coverage

- E-beam evaporation
- Sputtering / IBS
- Molecular beam epitaxy

## Characterization of high-finesse mirrors

- Determination of stop-band width FTS
- Direct transmission
- Absorption measurements (PCI)
- Loss measurements via CRD

Thank you for your attention!!!

???

